

## INTERIOR DOORS

REEB® IN-STOCK PRIMED STILE & RAIL DOOR CATALOG



## Elevate Your Home with Interior Primed Stile & Rail Doors

Primed stile and rail doors are an ideal choice for homeowners seeking to add a clean look to their Modern, Traditional or Craftsman style homes. They feature architecturally correct layouts, crisp shadow lines and highly defined panels, providing a superior level of detail. These doors are an excellent choice for discerning homeowners seeking increased strength, better durability and greater life expectancy at a similar price point to their molded door counterparts.

# Table of Contents

<b>Primed Doors</b>		<b>Contemporary Flush MDF</b>	<b>40</b>	<b>Locks</b>	<b>62</b>
<b>Construction</b>	<b>4</b>	<b>Transoms</b>	<b>44</b>	› Standard Residential Series	62
<b>Primed Doors</b>	<b>6</b>	<b>Fire-Rated Doors</b>	<b>46</b>	› Builder's Series	63
<b>9/16" Single Hip Raised Panel</b>	<b>6</b>	<b>1-1/4" Raised Panel</b>	<b>46</b>	<b>Catches</b>	<b>64</b>
› Ovolo Sticking	6	› Ovolo Sticking	46	<b>Image Index</b>	<b>65</b>
<b>3/8" MDF Flat Panel</b>	<b>10</b>	<b>13/16" Flat Panel</b>	<b>48</b>	<b>Index</b>	<b>66</b>
› Ovolo Sticking	10	› Ovolo Sticking	48	<b>Resources</b>	<b>70</b>
› Shaker Sticking	12	› Shaker Sticking	50	<b>Handling</b>	<b>71</b>
<b>5/8" MDF Flat Panel</b>	<b>16</b>	<b>Primed Barn Doors</b>	<b>52</b>		
› Ovolo Sticking	16	<b>9/16" Plank Panel</b>	<b>52</b>		
› Shaker Sticking	18	› Z Layout	52		
		› K Layout	53		
<b>French 1-1/4" Bar</b>	<b>20</b>	<b>Barn Door Hardware</b>	<b>54</b>		
› Clear Glass	20	<b>Barnfold® Hardware</b>	<b>55</b>		
› Frit Glass	24				
<b>French, Ovolo Sticking</b>	<b>26</b>	<b>Flat Frames</b>	<b>56</b>		
› Decorative Glass	26	<b>Rabbeted Frames</b>	<b>57</b>		
› Clear Glass	28	› Single Rabbeted	57		
› White Laminate Glass	29	› Double Rabbeted	57		
› Frit Glass	30				
		<b>Split Frames</b>	<b>58</b>		
<b>French, Shaker Sticking</b>	<b>31</b>	<b>Stops</b>	<b>58</b>		
› Clear Glass	31	<b>Sills</b>	<b>59</b>		
› Frit Glass	32				
<b>Louvers</b>		<b>Hinges</b>	<b>60</b>		
› 1-1/4" Louver Slats	34	› Baldwin®	61		
› 2-1/2" Louver Slats	36	› Reeb® Specialty Products	61		
› Contemporary Louver	38	› Emtek®	61		

# Primed Doors Construction

Primed stile and rail doors are wood components joined together with dowel pins. The stiles and rails have an engineered wood core covered with an MDF veneer creating an excellent surface for painting. Constructing a door with different components brings definition that cannot be replicated by a molded door.

**Rail:** The horizontal component of the door, crafted with a solid engineered core for lasting performance.

**Veneer:** An MDF veneer is permanently bonded to the engineered wood core, eliminating dents, dings, and gouges which makes a superior paint surface.

**Stile:** The stiles have a solid wood engineered core for added strength, stability, and reduced sound transmission.



## Solid Engineered Core

Built for strength and stability, stiles and rails feature a solid engineered core, with some doors using wood block or wood stave for added durability.

**Panel/Glass:** Flat and Raised Panels are made with MDF for a smooth paint finish, stability, and comply with no added formaldehyde regulation.




**Dowel Pins:** Traditional dowel pins securely join the stiles and rails, reinforcing the door's strength.



### Sharp Detail

Primed stile and rail doors join components together to create sharp shadow lines on all sticking.



### Architecturally Correct

Each door is made with perfectly proportioned stiles, rails and panels that are created individually to ensure that every door is architecturally correct.



### Panel Design

Choose from flat panels for a sleek look or raised panels with single hip detailing for added depth.



### Glass Designs

Select a full glass panel for an open feel or divided lites with bars for a classic, timeless look.

# Primed

## 9/16" Single Hip Raised Panel



### OVOLLO STICKING



#### PR82R 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking

1/0 x 6/8	2/0 x 6/8	—	2/6 x 7/0	2/4 x 8/0
1/2 x 6/8	2/2 x 6/8	1/6 x 7/0	2/8 x 7/0	2/6 x 8/0
1/3 x 6/8	2/4 x 6/8	1/8 x 7/0	2/10 x 7/0	2/8 x 8/0
1/4 x 6/8	2/6 x 6/8	1/10 x 7/0	3/0 x 7/0	2/10 x 8/0
1/6 x 6/8	2/8 x 6/8	2/0 x 7/0	—	3/0 x 8/0
1/8 x 6/8	2/10 x 6/8	2/2 x 7/0	1/6 x 8/0	5/0 x 6/8
1/10 x 6/8	3/0 x 6/8	2/4 x 7/0	2/0 x 8/0	6/0 x 6/8




#### PR82R 1-3/8" Bifold

9/16" Raised Panel,  
Ovolo Sticking

2/0 x 6/8
2/6 x 6/8
3/0 x 6/8
4/0 x 6/8
5/0 x 6/8
6/0 x 6/8






Panel Profile,  
Ovolo Sticking



## OVOLLO STICKING

SIZES 2/4 AND UP HAVE WIDE (5-1/2") STILES



### PR82R 1-3/4"

9/16" Raised Panel,  
Ovolo Sticking

1/0 x 6/8	2/6 x 6/8	1/8 x 7/0	1/6 x 8/0
1/2 x 6/8	2/8 x 6/8	1/10 x 7/0	2/0 x 8/0
1/3 x 6/8	2/10 x 6/8	2/4 x 8/0	
1/4 x 6/8	3/0 x 6/8	2/2 x 7/0	2/6 x 8/0
1/6 x 6/8	2/4 x 7/0	2/8 x 8/0	
1/8 x 6/8	1/0 x 7/0	2/6 x 7/0	2/10 x 8/0
1/10 x 6/8	1/2 x 7/0	2/8 x 7/0	3/0 x 8/0
2/0 x 6/8	1/3 x 7/0	2/10 x 7/0	
2/2 x 6/8	1/4 x 7/0	3/0 x 7/0	
2/4 x 6/8	1/6 x 7/0		

### PR82A 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking

1/0 x 6/8	2/6 x 6/8	3/0 x 7/0
1/2 x 6/8	2/8 x 6/8	
1/3 x 6/8	2/10 x 6/8	1/6 x 8/0
1/4 x 6/8	3/0 x 6/8	2/0 x 8/0
1/6 x 6/8	2/4 x 8/0	
1/8 x 6/8	1/6 x 7/0	2/6 x 8/0
1/10 x 6/8	2/0 x 7/0	2/8 x 8/0
2/0 x 6/8	2/4 x 7/0	2/10 x 8/0
2/2 x 6/8	2/6 x 7/0	3/0 x 8/0
2/4 x 6/8	2/8 x 7/0	

### PR82A 1-3/4"

9/16" Raised Panel,  
Ovolo Sticking

1/6 x 6/8	1/6 x 7/0	1/6 x 8/0
1/8 x 6/8	1/8 x 7/0	2/0 x 8/0
1/10 x 6/8	1/10 x 7/0	2/4 x 8/0
2/0 x 6/8	2/0 x 7/0	2/6 x 8/0
2/2 x 6/8	2/2 x 7/0	2/8 x 8/0
2/4 x 6/8	2/4 x 7/0	2/10 x 8/0
2/6 x 6/8	2/6 x 7/0	3/0 x 8/0
2/8 x 6/8	2/8 x 7/0	
2/10 x 6/8	2/10 x 7/0	
3/0 x 6/8	3/0 x 7/0	



# Primed

## 9/16" Single Hip Raised Panel

Bifolds are carton packed with track and hardware.

### OVOLY STICKING



#### PR44 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking

1/0 x 6/8	1/8 x 6/8	2/6 x 6/8
1/2 x 6/8	1/10 x 6/8	2/8 x 6/8
1/3 x 6/8	2/0 x 6/8	2/10 x 6/8
1/4 x 6/8	2/2 x 6/8	3/0 x 6/8
1/6 x 6/8	2/4 x 6/8	

#### PR44 1-3/8" Bifold

9/16" Raised Panel,  
Ovolo Sticking

2/0 x 6/8
2/6 x 6/8
3/0 x 6/8
4/0 x 6/8
5/0 x 6/8
6/0 x 6/8

#### PR44 1-3/4"


9/16" Raised Panel,  
Ovolo Sticking

1/6 x 6/8	2/4 x 6/8
1/8 x 6/8	2/6 x 6/8
1/10 x 6/8	2/8 x 6/8
2/0 x 6/8	2/10 x 6/8
2/2 x 6/8	3/0 x 6/8

#### PR55R 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking

1/6 x 6/8	2/4 x 6/8	2/10 x 6/8
1/8 x 6/8	2/6 x 6/8	3/0 x 6/8
2/0 x 6/8	2/8 x 6/8	



#### PR66 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking


1/0 x 6/8	1/6 x 6/8	2/2 x 6/8	2/10 x 6/8
1/2 x 6/8	1/8 x 6/8	2/4 x 6/8	3/0 x 6/8
1/3 x 6/8	1/10 x 6/8	2/6 x 6/8	
1/4 x 6/8	2/0 x 6/8	2/8 x 6/8	



#### PR66 1-3/8" Bifold

9/16" Raised Panel,  
Ovolo Sticking

2/0 x 6/8	5/0 x 6/8
2/6 x 6/8	6/0 x 6/8
3/0 x 6/8	
4/0 x 6/8	



#### PR66 1-3/4"

9/16" Raised Panel,  
Ovolo Sticking

1/6 x 6/8	2/2 x 6/8	2/10 x 6/8
1/8 x 6/8	2/4 x 6/8	3/0 x 6/8
1/10 x 6/8	2/6 x 6/8	
2/0 x 6/8	2/8 x 6/8	



#### PR56R 1-3/8"

9/16" Raised Panel,  
Ovolo Sticking

1/6 x 8/0	2/8 x 8/0
2/0 x 8/0	3/0 x 8/0
2/4 x 8/0	
2/6 x 8/0	



# Primed

3/8" MDF Flat Panel




## OVOLLO STICKING



Panel Profile,  
Ovololo Sticking




**PR8020 1-3/8"**  
3/8" MDF Flat Panel,  
Ovololo Sticking



**PR8082 1-3/8"**  
3/8" MDF Flat Panel,  
Ovololo Sticking

1/0 x 6/8
1/2 x 6/8
1/3 x 6/8
1/4 x 6/8
1/5 x 6/8
1/6 x 6/8
1/7 x 6/8
1/8 x 6/8
1/9 x 6/8
1/10 x 6/8
2/0 x 6/8
2/2 x 6/8
2/4 x 6/8
2/6 x 6/8
2/8 x 6/8
2/10 x 6/8
3/0 x 6/8
1/6 x 8/0
1/8 x 8/0
1/10 x 8/0
2/0 x 8/0
2/2 x 8/0
2/4 x 8/0
2/6 x 8/0
2/8 x 8/0
2/10 x 8/0
3/0 x 8/0
1/6 x 8/0
1/8 x 8/0
1/10 x 8/0
2/0 x 8/0
2/2 x 8/0
2/4 x 8/0
2/6 x 8/0
2/8 x 8/0
2/10 x 8/0
3/0 x 8/0


## OVOLO STICKING



### PR8044 1-3/8" \*

3/8" MDF Flat Panel,  
Ovolo Sticking

2/0 x 6/8  
2/2 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



### PR8040 1-3/8"

3/8" MDF Flat Panel,  
Ovolo Sticking

1/6 x 6/8	3/0 x 6/8	2/6 x 7/0
2/0 x 6/8	—	2/8 x 7/0
2/4 x 6/8	1/6 x 7/0	3/0 x 7/0
2/6 x 6/8	2/0 x 7/0	
2/8 x 6/8	2/4 x 7/0	



### PR8055 1-3/8"

3/8" MDF Flat Panel,  
Ovolo Sticking

1/6 x 6/8	2/4 x 6/8
1/8 x 6/8	2/6 x 6/8
1/10 x 6/8	2/8 x 6/8
2/0 x 6/8	2/10 x 6/8
2/2 x 6/8	3/0 x 6/8



### PR8055 1-3/8" (8/0)

3/8" MDF Flat Panel,  
Ovolo Sticking


1/6 x 8/0	2/10 x 8/0
2/0 x 8/0	3/0 x 8/0
2/4 x 8/0	
2/6 x 8/0	
2/8 x 8/0	



Bifolds are carton packed with track and hardware.  
\*The PR8044 in sizes 1/0 - 1/10 is a narrow layout with only 2 panels. Please use the PR8782 for these sizes.

# Primed

3/8" MDF Flat Panel



Panel Profile,  
Shaker Sticking



## SHAKER STICKING



### PR8720 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking

1/0 x 6/8	2/4 x 6/8	2/6 x 7/0	2/2 x 8/0
1/2 x 6/8	2/6 x 6/8	2/8 x 7/0	2/4 x 8/0
1/3 x 6/8	2/8 x 6/8	2/10 x 7/0	2/6 x 8/0
1/4 x 6/8	2/10 x 6/8	3/0 x 7/0	2/8 x 8/0
1/6 x 6/8	3/0 x 6/8	_____	2/10 x 8/0
1/8 x 6/8	_____	1/6 x 8/0	3/0 x 8/0
1/10 x 6/8	1/6 x 7/0	1/8 x 8/0	
2/0 x 6/8	2/0 x 7/0	1/10 x 8/0	
2/2 x 6/8	2/4 x 7/0	2/0 x 8/0	

### PR8720 1-3/8" Bifold

3/8" MDF Flat Panel,  
Shaker Sticking

2/0 x 6/8
2/6 x 6/8
3/0 x 6/8
4/0 x 6/8
5/0 x 6/8
6/0 x 6/8

### PR8782 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking

1/0 x 6/8	2/4 x 6/8	2/6 x 7/0	2/2 x 8/0
1/2 x 6/8	2/6 x 6/8	2/8 x 7/0	2/4 x 8/0
1/3 x 6/8	2/8 x 6/8	2/10 x 7/0	2/6 x 8/0
1/4 x 6/8	2/10 x 6/8	3/0 x 7/0	2/8 x 8/0
1/6 x 6/8	3/0 x 6/8	_____	2/10 x 8/0
1/8 x 6/8	_____	1/6 x 8/0	3/0 x 8/0
1/10 x 6/8	1/6 x 7/0	1/8 x 8/0	
2/0 x 6/8	2/0 x 7/0	1/10 x 8/0	
2/2 x 6/8	2/4 x 7/0	2/0 x 8/0	

### PR8782 1-3/8" Bifold

3/8" MDF Flat Panel,  
Shaker Sticking


2/0 x 6/8
2/6 x 6/8
3/0 x 6/8
4/0 x 6/8
5/0 x 6/8
6/0 x 6/8



# Primed

## 3/8" MDF Flat Panel

### SHAKER STICKING



#### PR8730 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking


1/0 x 6/8	2/2 x 6/8	1/8 x 7/0	3/0 x 7/0
1/2 x 6/8	2/4 x 6/8	1/10 x 7/0	<hr/>
1/3 x 6/8	2/6 x 6/8	2/0 x 7/0	1/6 x 8/0
1/4 x 6/8	2/8 x 6/8	2/2 x 7/0	2/0 x 8/0
1/6 x 6/8	2/10 x 6/8	2/4 x 7/0	2/4 x 8/0
1/8 x 6/8	3/0 x 6/8	2/6 x 7/0	2/6 x 8/0
1/10 x 6/8	<hr/>	2/8 x 7/0	2/8 x 8/0
2/0 x 6/8	1/6 x 7/0	2/10 x 7/0	3/0 x 8/0



#### PR8730 1-3/8" Bifold

3/8" MDF Flat Panel,  
Shaker Sticking


2/0 x 6/8
2/6 x 6/8
3/0 x 6/8
4/0 x 6/8
5/0 x 6/8
6/0 x 6/8



#### PR8760 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking


1/0 x 6/8	1/10 x 6/8	2/10 x 6/8	2/6 x 7/0
1/2 x 6/8	2/0 x 6/8	3/0 x 6/8	2/8 x 7/0
1/3 x 6/8	2/2 x 6/8	<hr/>	2/10 x 7/0
1/4 x 6/8	2/4 x 6/8	1/6 x 7/0	3/0 x 7/0
1/6 x 6/8	2/6 x 6/8	2/0 x 7/0	2/4 x 7/0
1/8 x 6/8	2/8 x 6/8	2/4 x 7/0	<hr/>



#### PR8760 1-3/8" (8/0)

3/8" MDF Flat Panel,  
Shaker Sticking


1/6 x 8/0	2/4 x 8/0
1/8 x 8/0	2/6 x 8/0
1/10 x 8/0	2/8 x 8/0
2/0 x 8/0	2/10 x 8/0
2/2 x 8/0	3/0 x 8/0



#### PR8740 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking


1/6 x 6/8	3/0 x 6/8	2/6 x 7/0
2/0 x 6/8	<hr/>	2/8 x 7/0
2/4 x 6/8	1/6 x 7/0	3/0 x 7/0
2/6 x 6/8	2/0 x 7/0	
2/8 x 6/8	2/4 x 7/0	



#### PR8744 1-3/8"\*

3/8" MDF Flat Panel,  
Shaker Sticking


2/0 x 6/8	2/10 x 6/8
2/2 x 6/8	3/0 x 6/8
2/4 x 6/8	
2/6 x 6/8	
2/8 x 6/8	



#### PR8762 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking

1/6 x 6/8	2/10 x 6/8
2/0 x 6/8	3/0 x 6/8
2/4 x 6/8	
2/6 x 6/8	
2/8 x 6/8	




#### PR8762 1-3/8" (8/0)

3/8" MDF Flat Panel,  
Shaker Sticking

2/0 x 8/0
2/4 x 8/0
2/6 x 8/0
2/8 x 8/0
3/0 x 8/0




### SHAKER STICKING



#### PR8755 1-3/8"

3/8" MDF Flat Panel,  
Shaker Sticking

1/0 x 6/8	1/10 x 6/8	2/10 x 6/8	2/6 x 7/0
1/2 x 6/8	2/0 x 6/8	3/0 x 6/8	2/8 x 7/0
1/3 x 6/8	2/2 x 6/8	—	2/10 x 7/0
1/4 x 6/8	2/4 x 6/8	1/6 x 7/0	3/0 x 7/0
1/6 x 6/8	2/6 x 6/8	2/0 x 7/0	4/0 x 6/8
1/8 x 6/8	2/8 x 6/8	2/4 x 7/0	5/0 x 6/8



#### PR8755 1-3/8" Bifold

3/8" MDF Flat Panel,  
Shaker Sticking

2/0 x 6/8	2/10 x 8/0
2/6 x 6/8	2/0 x 8/0
3/0 x 6/8	3/0 x 8/0
4/0 x 6/8	2/4 x 8/0
5/0 x 6/8	2/6 x 8/0
6/0 x 6/8	2/8 x 8/0



#### PR8755 1-3/8" (8/0)


3/8" MDF Flat Panel,  
Shaker Sticking

1/6 x 8/0	2/10 x 8/0
2/0 x 8/0	3/0 x 8/0
2/4 x 8/0	
2/6 x 8/0	
2/8 x 8/0	

\*The PR8744 in sizes 1/0 - 1/10 is a narrow layout with only 2 panels. Please use the PR8782 for these sizes.

# Primed

5/8" MDF Flat Panel



Panel Profile,  
Ovolo Sticking




## OVOLLO STICKING



### PR8020 1-3/4"

5/8" MDF Flat Panel,  
Ovolo Sticking

1/0 x 6/8	2/8 x 6/8	2/0 x 7/0	2/6 x 8/0
1/2 x 6/8	2/10 x 6/8	2/2 x 7/0	2/8 x 8/0
1/3 x 6/8	3/0 x 6/8	2/4 x 7/0	2/10 x 8/0
1/4 x 6/8	<hr/>	2/6 x 7/0	3/0 x 8/0
1/6 x 6/8	1/0 x 7/0	2/8 x 7/0	
1/8 x 6/8	1/2 x 7/0	2/10 x 7/0	
1/10 x 6/8	1/3 x 7/0	3/0 x 7/0	
2/0 x 6/8	1/4 x 7/0	<hr/>	
2/2 x 6/8	1/6 x 7/0	1/6 x 8/0	
2/4 x 6/8	1/8 x 7/0	2/0 x 8/0	
2/6 x 6/8	1/10 x 7/0	2/4 x 8/0	



### PR8082 1-3/4"


5/8" MDF Flat Panel,  
Ovolo Sticking

1/0 x 6/8	2/4 x 6/8	2/0 x 7/0	1/8 x 8/0
1/2 x 6/8	2/6 x 6/8	2/2 x 7/0	1/10 x 8/0
1/3 x 6/8	2/8 x 6/8	2/4 x 7/0	2/0 x 8/0
1/4 x 6/8	2/10 x 6/8	2/6 x 7/0	2/2 x 8/0
1/6 x 6/8	3/0 x 6/8	2/8 x 7/0	2/4 x 8/0
1/8 x 6/8	<hr/>	2/10 x 7/0	2/6 x 8/0
1/10 x 6/8	1/6 x 7/0	3/0 x 7/0	2/8 x 8/0
2/0 x 6/8	1/8 x 7/0	<hr/>	2/10 x 8/0
2/2 x 6/8	1/10 x 7/0	1/6 x 8/0	3/0 x 8/0



# Primed

5/8" MDF Flat Panel



Panel Profile,  
Shaker Sticking




## SHAKER STICKING



### PR8720 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking


1/0 x 6/8	2/2 x 6/8	1/2 x 7/0	2/4 x 7/0	1/10 x 8/0
1/2 x 6/8	2/4 x 6/8	1/3 x 7/0	2/6 x 7/0	2/0 x 8/0
1/3 x 6/8	2/6 x 6/8	1/4 x 7/0	2/8 x 7/0	2/2 x 8/0
1/4 x 6/8	2/8 x 6/8	1/6 x 7/0	2/10 x 7/0	2/4 x 8/0
1/6 x 6/8	2/10 x 6/8	1/8 x 7/0	3/0 x 7/0	2/6 x 8/0
1/8 x 6/8	3/0 x 6/8	1/10 x 7/0	2/8 x 8/0	3/0 x 8/0
1/10 x 6/8	—	2/0 x 7/0	1/6 x 8/0	2/10 x 8/0
2/0 x 6/8	1/0 x 7/0	2/2 x 7/0	1/8 x 8/0	3/0 x 8/0



### PR8782 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking


1/0 x 6/8	2/2 x 6/8	1/8 x 7/0	3/0 x 7/0	2/6 x 8/0
1/2 x 6/8	2/4 x 6/8	1/10 x 7/0	—	2/8 x 8/0
1/3 x 6/8	2/6 x 6/8	2/0 x 7/0	1/6 x 8/0	2/10 x 8/0
1/4 x 6/8	2/8 x 6/8	2/2 x 7/0	1/8 x 8/0	3/0 x 8/0
1/6 x 6/8	2/10 x 6/8	2/4 x 7/0	1/10 x 8/0	—
1/8 x 6/8	3/0 x 6/8	2/6 x 7/0	2/0 x 8/0	—
1/10 x 6/8	—	2/8 x 7/0	2/2 x 8/0	—
2/0 x 6/8	1/6 x 7/0	2/10 x 7/0	2/4 x 8/0	—



### PR8730 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking


1/6 x 6/8	1/6 x 7/0	1/6 x 8/0
2/0 x 6/8	2/0 x 7/0	2/0 x 8/0
2/4 x 6/8	2/4 x 7/0	2/4 x 8/0
2/6 x 6/8	2/6 x 7/0	2/6 x 8/0
2/8 x 6/8	2/8 x 7/0	2/8 x 8/0
2/10 x 6/8	2/10 x 7/0	3/0 x 8/0
3/0 x 6/8	3/0 x 7/0	—



### PR8760 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking

1/6 x 6/8
2/0 x 6/8
2/4 x 6/8
2/6 x 6/8
2/8 x 6/8
2/10 x 6/8
3/0 x 6/8



### PR8740 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking

1/6 x 6/8
2/0 x 6/8
2/4 x 6/8
2/6 x 6/8
2/8 x 6/8
3/0 x 6/8




### PR8755 1-3/4"

5/8" MDF Flat Panel,  
Shaker Sticking

1/6 x 6/8
2/0 x 6/8
2/4 x 6/8
2/6 x 6/8
2/8 x 6/8
2/10 x 6/8
3/0 x 6/8

# Primed

1-1/4" BAR FRENCH



Bar Profile,  
Ovolo Sticking



**CLEAR GLASS**



**PR8010 1-3/8"**

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/6 x 6/8  
2/0 x 6/8  
2/6 x 6/8



**PR8010 1-3/4"**

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/6 x 6/8  
2/0 x 6/8



**PR8012 1-3/8" (8/0)**

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/6 x 8/0  
2/0 x 8/0



**PR8012 1-3/4" (8/0)**

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/6 x 8/0  
2/0 x 8/0

# Primed

## 1-1/4" BAR FRENCH

### CLEAR GLASS



#### PR8015 1-3/8"

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



#### PR8015 1-3/4"

1-1/4" Bar, Clear Glass,  
Ovolo Sticking


2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



#### PR8018 1-3/8" (8/0)

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

2/4 x 8/0  
2/6 x 8/0  
2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0



#### PR8018 1-3/4" (8/0)


1-1/4" Bar, Clear Glass,  
Ovolo Sticking

2/4 x 8/0  
2/6 x 8/0  
2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0



# Primed

1-1/4" BAR FRENCH




Bar Profile,  
Ovolo Sticking






#### FRIT GLASS



##### PR8010F 1-3/8"

1-1/4" Bar, Frit Glass,  
Ovolo Sticking


1/6 x 6/8  
2/0 x 6/8



##### PR8012F 1-3/8" (8/0)

1-1/4" Bar, Frit Glass,  
Ovolo Sticking


1/6 x 8/0  
2/0 x 8/0



##### PR8015F 1-3/8"

1-1/4" Bar, Frit Glass,  
Ovolo Sticking

2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



##### PR8018F 1-3/8" (8/0)


1-1/4" Bar, Frit Glass  
Ovolo Sticking,

2/4 x 8/0  
2/6 x 8/0  
2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0



# Primed

FRENCH




Panel Profile,  
Ovolo Sticking





## DECORATIVE GLASS



### PR8490 1-3/8"


Clear Art on Satin Etch Glass,  
Ovolo Sticking

2/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
3/0 x 6/8

# Primed

## FRENCH

### CLEAR GLASS



### PR8001 1-3/8"

Clear Glass,  
Ovolo Sticking

1/6 x 6/8	2/8 x 6/8	1/6 x 8/0	2/8 x 8/0
2/10 x 6/8	2/10 x 6/8	2/10 x 8/0	2/10 x 8/0
2/4 x 6/8	3/0 x 6/8	2/4 x 8/0	3/0 x 8/0
2/6 x 6/8		2/6 x 8/0	


Panel Profile,  
Ovolo Sticking



# Primed

## FRENCH

## WHITE LAMINATE GLASS




## Panel Profile, Ovolo Sticking

PR1501WL 1-3/8"

## White Laminate Glass, Ovolo Sticking

$$\begin{array}{cccc}
 2/0 \times 6/8 & 2/8 \times 6/8 & 2/0 \times 8/0 & 2/8 \times 8/0 \\
 2/4 \times 6/8 & 3/0 \times 6/8 & 2/4 \times 8/0 & 3/0 \times 8/0 \\
 2/6 \times 6/8 & & 2/6 \times 8/0
 \end{array}$$



# Primed

## FRENCH


### FRIT GLASS



#### PR8001F 1-3/8"

Frit Glass,  
Ovolo Sticking

1/6 x 6/8	2/8 x 6/8	1/6 x 8/0	2/8 x 8/0
2/0 x 6/8	2/10 x 6/8	2/0 x 8/0	2/10 x 8/0
2/4 x 6/8	3/0 x 6/8	2/4 x 8/0	3/0 x 8/0
2/6 x 6/8		2/6 x 8/0	




Panel Profile,  
Ovolo Sticking



# Primed

## FRENCH

### CLEAR GLASS



Glass Profile,  
Shaker Sticking

### PR8711 1-3/8"

Clear Glass,  
Shaker Sticking

1/6 x 6/8    2/6 x 8/0  
2/0 x 6/8    2/8 x 8/0  
2/4 x 6/8    3/0 x 8/0  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



### PR8711 1-3/4"

Clear Glass,  
Shaker Sticking

2/0 x 6/8    2/8 x 7/0  
2/6 x 6/8    3/0 x 7/0  
2/8 x 6/8  
3/0 x 6/8



# Primed

## FRENCH


### FRIT GLASS



#### PR8711F 1-3/8"

Frit Glass,  
Shaker Sticking

1/6 x 6/8    2/6 x 8/0  
2/0 x 6/8    2/8 x 8/0  
2/4 x 6/8    3/0 x 8/0  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



Glass Profile,  
Shaker Sticking



#### PR8711F 1-3/4"


Frit Glass,  
Shaker Sticking

2/0 x 6/8    2/8 x 7/0  
2/6 x 6/8    3/0 x 7/0  
2/8 x 6/8  
3/0 x 6/8






**FRIT GLASS**



**PR8733F 1-3/8"**

Frit Glass,  
Shaker Sticking


2/6 x 6/8  
2/8 x 6/8  
3/0 x 6/8



**PR8733F 1-3/8" (8/0)**

Frit Glass,  
Shaker Sticking


2/6 x 8/0  
2/8 x 8/0  
3/0 x 8/0



**PR8735F 1-3/8"**

Frit Glass,  
Shaker Sticking

2/6 x 6/8  
2/8 x 6/8  
3/0 x 6/8



**PR8735F 1-3/8" (8/0)**

Frit Glass,  
Shaker Sticking

2/6 x 8/0  
2/8 x 8/0  
3/0 x 8/0




CLEAR




# Primed

## LOUVERS




When the blind side is on the hinge side, the louvers run **down**, meaning you **cannot** see into the next room.




When the blind side is on the stop side, the louvers run **up**, meaning you **can** see into the next room.

When ordering a louver door, it is important to specify which side is the blind side. View the door as if you are in the inside of the room and the door is opening toward you.




Louver Profile,  
Louvered Sticking

### 1-1/4" LOUVER SLATS



**PR730 1-3/8"**  
Primed, 1-1/4" Slats,  
Louvered Sticking

1/6 x 6/8	2/4 x 6/8	1/6 x 7/0	2/10 x 7/0	2/4 x 8/0
1/8 x 6/8	2/6 x 6/8	2/0 x 7/0	3/0 x 7/0	2/6 x 8/0
1/10 x 6/8	2/8 x 6/8	2/4 x 7/0		2/8 x 8/0
2/0 x 6/8	2/10 x 6/8	2/6 x 7/0	1/6 x 8/0	3/0 x 8/0
2/2 x 6/8	3/0 x 6/8	2/8 x 7/0	2/0 x 8/0	



**PR730 1-3/4"**  
Primed, 1-1/4" Slats,  
Louvered Sticking

1/6 x 6/8	2/10 x 6/8
2/0 x 6/8	3/0 x 6/8
2/4 x 6/8	
2/6 x 6/8	
2/8 x 6/8	


## 1-1/4" LOUVER SLATS



### PRN730FJ 1-1/8" Bifold

Primed, 1-1/4" Slats, 1-1/8" Modified Finger Joint, Louvered Sticking

2/0 x 6/8    4/0 x 6/8  
2/4 x 6/8    4/8 x 6/8  
2/6 x 6/8    5/0 x 6/8  
2/8 x 6/8    5/4 x 6/8  
3/0 x 6/8    6/0 x 6/8



### PR732 1-3/8"

Primed, 1-1/4" Slats, Louvered Sticking


1/6 x 6/8    1/6 x 7/0  
2/0 x 6/8    2/0 x 7/0  
2/2 x 6/8    2/4 x 7/0  
2/4 x 6/8    2/6 x 7/0  
2/6 x 6/8    2/8 x 7/0  
2/8 x 6/8    3/0 x 7/0  
2/10 x 6/8  
3/0 x 6/8



### PRN732FJ 1-1/8" Bifold

Primed, 1-1/4" Slats, 1-1/8" Modified Finger Joint, Louvered Sticking

2/0 x 6/8  
2/6 x 6/8  
3/0 x 6/8  
4/0 x 6/8  
5/0 x 6/8  
6/0 x 6/8



### PR742 1-3/8"

Primed, 1-1/4" Slats, Louvered Sticking


1/6 x 6/8  
2/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8




Bifolds are carton packed with track and hardware.

# Primed

## LOUVERS




When the blind side is on the hinge side, the louvers run **down**, meaning you **cannot** see into the next room.



When the blind side is on the stop side, the louvers run **up**, meaning you **can** see into the next room.

When ordering a louver door, it is important to specify which side is the blind side. View the door as if you are in the inside of the room and the door is opening toward you.




Louver Profile,  
Louvered Sticking






**2-1/2" LOUVER SLATS**




**PR730W 1-3/8"**  
Primed, 2-1/2" Slats,  
Louvered Sticking

1/6 x 6/8  
2/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



**PR730W 1-3/8" Bifold**  
Primed, 2-1/2" Slats,  
Louvered Sticking

2/0 x 6/8  
2/6 x 6/8  
3/0 x 6/8  
4/0 x 6/8  
5/0 x 6/8  
6/0 x 6/8



**PR732W 1-3/8"**  
Primed, 2-1/2" Slats,  
Louvered Sticking

1/6 x 6/8  
2/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8


Bifolds are carton packed with track and hardware.

# Primed

## CONTEMPORARY LOUVERS



Reeb® contemporary louver doors have shaker sticking and unique slotted louver ventilation. Cut at an angle into the panel, the slotted louvers give the same ventilation possibilities as louver slats, but with a different aesthetic. This contemporary door pairs well with other shaker-style flat panel doors.



Slotted Louver Profile,  
Shaker Sticking






### SLOTTED LOUVER



#### PR730F 1-3/8"

3/8" Flat Panel Slotted Louver, Shaker Sticking


1/6 x 6/8    2/6 x 6/8  
2/0 x 6/8    2/8 x 6/8  
2/4 x 6/8    3/0 x 6/8



#### PR730F 1-3/8" Bifold

3/8" Flat Panel Slotted Louver, Shaker Sticking

2/0 x 6/8    4/0 x 6/8  
2/6 x 6/8    5/0 x 6/8  
3/0 x 6/8    6/0 x 6/8



#### PR730F 1-3/4"

3/8" Flat Panel Slotted Louver, Shaker Sticking


1/6 x 6/8	2/10 x 6/8	2/4 x 7/0
2/0 x 6/8	3/0 x 6/8	2/6 x 7/0
2/4 x 6/8	_____	2/8 x 7/0
2/6 x 6/8	1/6 x 7/0	2/10 x 7/0
2/8 x 6/8	2/0 x 7/0	3/0 x 7/0

Bifolds are carton packed with track and hardware.

# Primed

## CONTEMPORARY MDF

Reeb's modern-style Flush MDF doors have a premium 1/4" thick veneer. Unlike traditional flush doors with a thin veneer over a solid particle core where the grooves cut into the door must be shallow, the grooves in RSP flush doors are cut 1/8" deep, resulting in crisp shadow lines for greater definition.



These contemporary doors have a unique lattice wood core that provides exceptional strength and improved stability. They have the feel of a real wood door without the weight that can lead to hinge issues. These doors can be prepped for the typical backset options or a mortise pocket.





#### FLUSH MDF



#### PRF2302 1-3/8"

Flush MDF,  
Square Grooves

1/6 x 6/8  
2/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8  
2/8 x 6/8  
3/0 x 6/8



#### PRF2302 1-3/4"

Flush MDF,  
Square Grooves

1/6 x 6/8	1/6 x 7/0	1/6 x 8/0
2/0 x 6/8	2/0 x 7/0	2/0 x 8/0
2/4 x 6/8	2/4 x 7/0	2/4 x 8/0
2/6 x 6/8	2/6 x 7/0	2/6 x 8/0
2/8 x 6/8	2/8 x 7/0	2/8 x 8/0
2/10 x 6/8	2/10 x 7/0	2/10 x 8/0
3/0 x 6/8	3/0 x 7/0	3/0 x 8/0

# Primed

## CONTEMPORARY MDF

### FLUSH MDF



#### PRF2355 1-3/8"

Flush MDF,  
Square Grooves

1/6 x 6/8    2/8 x 6/8  
2/0 x 6/8    3/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8



#### PRF2355 1-3/4"

Flush MDF,  
Square Grooves


1/6 x 6/8    3/0 x 6/8    2/8 x 7/0  
2/0 x 6/8          2/10 x 7/0  
2/4 x 6/8    1/6 x 7/0        
2/6 x 6/8    2/0 x 7/0    3/0 x 8/0  
2/8 x 6/8    2/4 x 7/0  
2/10 x 6/8    2/6 x 7/0



#### PRF2356 1-3/4" (8/0)

Flush MDF,  
Square Grooves


1/6 x 8/0    2/8 x 8/0  
2/0 x 8/0    2/10 x 8/0  
2/4 x 8/0    3/0 x 8/0  
2/6 x 8/0



#### PRF2315 1-3/8"

Flush MDF,  
Square Grooves

1/6 x 6/8    2/8 x 6/8  
2/0 x 6/8    3/0 x 6/8  
2/4 x 6/8  
2/6 x 6/8






### FLUSH MDF



**PRF2315 1-3/4"**

Flush MDF,  
Square Grooves


1/6 x 6/8	2/0 x 7/0	2/4 x 8/0
2/0 x 6/8	2/4 x 7/0	2/6 x 8/0
2/4 x 6/8	2/6 x 7/0	2/8 x 8/0
2/6 x 6/8	2/8 x 7/0	2/10 x 8/0
2/8 x 6/8	2/10 x 7/0	3/0 x 8/0
2/10 x 6/8	3/0 x 7/0	
3/0 x 6/8		
3/0 x 7/0	1/6 x 8/0	
1/6 x 7/0	2/0 x 8/0	



**PRF2310 1-3/8"**

Flush MDF,  
Square Grooves


1/6 x 6/8
2/0 x 6/8
2/4 x 6/8
2/6 x 6/8
2/8 x 6/8




**PRF2310 1-3/4"**

Flush MDF,  
Square Grooves


1/6 x 6/8	2/0 x 7/0	2/4 x 8/0
2/0 x 6/8	2/4 x 7/0	2/6 x 8/0
2/4 x 6/8	2/6 x 7/0	2/8 x 8/0
2/6 x 6/8	2/8 x 7/0	2/10 x 8/0
2/8 x 6/8	2/10 x 7/0	3/0 x 8/0
2/10 x 6/8	3/0 x 7/0	
3/0 x 6/8		
3/0 x 7/0	1/6 x 8/0	
1/6 x 7/0	2/0 x 8/0	



**PRF2315**



**PRF2310**



**PRF2302**

For a consistent design,  
the strike side will always  
be on the stile line side  
of the door.

# Interior Door Units

After choosing the perfect door, there are additional features that can be included to complete your door unit. These include adding transoms and sidelites for more light, choosing a frame that matches your door, and selecting hardware to match your home's interior.

## INTERIOR TRANSMON




### PRT001

Primed, Clear Glass,  
Ovolo Sticking

2/6, 2/8 & 3/0 for use with Single Door  
4/0 x 1/0 for use with 2/0 Double Door  
5/0 x 1/0 for use with 2/6 Double Door  
6/0 x 1/0 for use with 3/0 Double Door

2/6 x 1/0    4/0 x 1/0  
2/8 x 1/0    5/0 x 1/0  
3/0 x 1/0    6/0 x 1/0



### PRT003

Primed, Divided Lites, Clear Glass  
Ovolo Sticking

For use with Single Door

2/6 x 1/0  
2/8 x 1/0  
3/0 x 1/0



### PRT004

Primed, Divided Lites, Clear Glass,  
Ovolo Sticking

For use with 2/0 Double Door

4/0 x 1/0



### PRT005

Primed, Divided Lites,  
Clear Glass, Ovolo Sticking

5/0 x 1/0 for use with 2/6 Double Door  
5/4 x 1/0 for use with 2/8 Double Door  
6/0 x 1/0 for use with 3/0 Double Door

5/0 x 1/0  
5/4 x 1/0  
6/0 x 1/0

## INTERIOR SIDELITES



### PR8706 1-3/8" (8/0)

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/2 x 8/0



### PR8705 1-3/8" (6/8)

1-1/4" Bar, Clear Glass,  
Ovolo Sticking

1/0 x 6/8  
1/2 x 6/8




# Primed

20 MINUTE FIRE-RATED DOORS

1-1/4" RAISED PANEL

These doors are labeled with a 20 minute positive pressure rating. The panels are layered with a fire rated material and the stiles are solid wood. Additional requirements may be necessary for door installation.




Panel Profile,  
Ovolo Sticking




**1-1/4" RAISED PANEL, OVOLO STICKING**




DOORS HAVE WIDE (5-1/2") STILES




DOORS HAVE WIDE (5-1/2") STILES



**PR66FR 1-3/4"**  
20 Minute Fire Rated  
1-1/4" Raised Panel,  
Ovolo Sticking



**PR55RFR 1-3/4"**  
20 Minute Fire Rated  
1-1/4" Raised Panel,  
Ovolo Sticking



**PR56RFR 1-3/4" (8/0)**  
20 Minute Fire Rated  
1-1/4" Raised Panel,  
Ovolo Sticking

**PR82RFR 1-3/4"**  
20 Minute Fire Rated  
1-1/4" Raised Panel,  
Ovolo Sticking

2/8 x 6/8   2/8 x 7/0   2/8 x 8/0  
2/10 x 6/8   2/10 x 7/0   2/10 x 8/0  
3/0 x 6/8   3/0 x 7/0   3/0 x 8/0

**PR82AFR 1-3/4"**  
20 Minute Fire Rated  
1-1/4" Raised Panel,  
Ovolo Sticking

2/8 x 6/8   2/8 x 7/0   2/8 x 8/0  
2/10 x 6/8   2/10 x 7/0   2/10 x 8/0  
3/0 x 6/8   3/0 x 7/0   3/0 x 8/0

2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8

2/8 x 6/8   3/0 x 7/0  
3/0 x 6/8

3/0 x 8/0




# Primed

## 20 MINUTE FIRE-RATED DOORS

### 13/16" FLAT PANEL

These doors are labeled with a 20 minute positive pressure rating. The panels are layered with a fire rated material and the stiles are solid wood. Additional requirements may be necessary for door installation.



Panel Profile,  
Ovolo Sticking



**13/16" FLAT PANEL, OVOLO STICKING**



**PR8020FR 1-3/4"**

20 Minute Fire Rated  
13/16" Flat Panel  
Ovolo Sticking

2/8 x 6/8   2/8 x 7/0   2/8 x 8/0  
2/10 x 6/8   2/10 x 7/0   2/10 x 8/0  
3/0 x 6/8   3/0 x 7/0   3/0 x 8/0



**PR8082FR 1-3/4"**

20 Minute Fire Rated  
13/16" Flat Panel  
Ovolo Sticking


2/8 x 6/8   2/8 x 7/0   2/8 x 8/0  
2/10 x 6/8   2/10 x 7/0   2/10 x 8/0  
3/0 x 6/8   3/0 x 7/0   3/0 x 8/0



**PR8055FR 1-3/4"**

20 Minute Fire Rated  
13/16" Flat Panel  
Ovolo Sticking

2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



**PR8055FR 1-3/4" (8/0)**

20 Minute Fire Rated  
13/16" Flat Panel  
Ovolo Sticking

2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0




# Primed

## 20 MINUTE FIRE-RATED DOORS

### 13/16" FLAT PANEL

These doors are labeled with a 20 minute positive pressure rating. The panels are layered with a fire rated material and the stiles are solid wood. Additional requirements may be necessary for door installation.



Panel Profile,  
Shaker Sticking




## 13/16" FLAT PANEL, SHAKER STICKING



### PR8720FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking


2/8 x 6/8    2/8 x 7/0    2/8 x 8/0  
2/10 x 6/8    2/10 x 7/0    2/10 x 8/0  
3/0 x 6/8    3/0 x 7/0    3/0 x 8/0



### PR8782FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking


2/8 x 6/8    2/8 x 7/0    2/8 x 8/0  
2/10 x 6/8    2/10 x 7/0    2/10 x 8/0  
3/0 x 6/8    3/0 x 7/0    3/0 x 8/0



### PR8760FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking


2/8 x 6/8    3/0 x 7/0  
2/10 x 6/8  
3/0 x 6/8



### PR8760FR 1-3/4" (8/0)

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking


2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0



### PR8730FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking

2/8 x 6/8    3/0 x 7/0    3/0 x 8/0  
3/0 x 6/8



### PR8740FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking


2/8 x 6/8    3/0 x 7/0  
3/0 x 6/8



### PR8755FR 1-3/4"

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking

2/8 x 6/8  
2/10 x 6/8  
3/0 x 6/8



### PR8755FR 1-3/4" (8/0)

20 Minute Fire Rated  
13/16" Flat Panel  
Shaker Sticking

2/8 x 8/0  
2/10 x 8/0  
3/0 x 8/0

# Barn Doors

9/16" Plank Panel

## Z LAYOUT




## PR180 1-3/8"

9/16" Plank Panel, Z Layout, Shaker Sticking

2/6 x 6/8   3/0 x 7/0   3/0 x 8/0  
2/8 x 6/8  
3/0 x 6/8



## LAYOUT OPTIONS




Panel Profile,  
Shaker Sticking  
(Shown from above)



# Barn Doors

9/16" Plank Panel

## K LAYOUT



## PR181 1-3/8"


9/16" Plank Panel, K Layout, Shaker Sticking

2/6 x 6/8   3/0 x 7/0   3/0 x 8/0  
2/8 x 6/8  
3/0 x 6/8




## LAYOUT OPTIONS


### STANDARD




### REVERSE



### UNIFORM A



### UNIFORM B



Panel Profile,  
Shaker Sticking  
(Shown from above)



Barn doors can be hung in different configurations according to design preference. Please be sure to specify when ordering.  
Primed barn doors come with groove already machined in the bottom of the door to be used with barn door hardware.

# Barn Door Hardware



Goldberg's line of interior, residential sliding barn door hardware kits makes the most of the available living space, while adding a rustic, yet elegant look. All major components are manufactured from steel and come with a 1-year warranty.

## AVAILABLE FINISHES



BLACK



SILVER



STAINLESS  
STEEL



ARCHITECTURAL  
BRONZE



7" Pull Handle



Privacy Latch



6" Flush Pull



Roller Hanger



7" Pull Handle



Privacy Latch



6" Flush Pull



Roller Hanger

# Barnfold® Hardware



Due to the wall space required for the long track, sometimes there is no room to install a conventional barn door. Barnfold® Series folding barn door hardware combines the style of the popular J-strap hangers with the space-saving convenience of bifold doors.

## AVAILABLE FINISHES



BLACK



Barnfold J-Strap  
Hanger



4" Pull Handle  
Hanger



Hinge



# Frames

## Flat Frames



*Flat frames come in a variety of species including solid and veneered wood. They include the need for a stop. This option may not be available in all markets so please confirm availability prior to ordering.*



PRIMED



CLEAR PINE



PINE VENEERED



KNOTTY ALDER VENEERED



FIR VENEERED



MAPLE VENEERED



SOLID POPLAR



PRIMED SOLID POPLAR



SOLID OAK



OAK VENEERED

# Rabbeted Frames



## Single Rabbeted

*Single rabbeted frames mimic the appearance of exterior frames for interior use. This option may not be available in all markets so please confirm availability prior to ordering.*



PRIMED



CLEAR PINE



PRIMED SOLID POPLAR



## Double Rabbeted

*Double rabbeted frames work well with either a 1-3/8" or 1-3/4" thick door. This option may not be available in all markets so please confirm availability prior to ordering.*



PRIMED



CLEAR PINE



CLEAR FIR



PRIMED SOLID POPLAR

# Frames



## Split Frames

*Split frames are two pieces of wood together which work well for odd wall sizes. Due to their construction, a split frame is able to work for a range of wall sizes. For example, Reeb® stocks a split frame that has a size range of 4-1/2" to 5-1/4" thick.*

Also with split frames is the availability to use interior casing. When installing a split frame with casing, the two pieces must be taken apart. This allows the unit to be shipped with the casing pre-attached and ready for a complete install. This option may not be available in all markets, so please confirm availability prior to ordering.



PRIMED SOLID POPLAR



SOLID OAK

## Stops

*Known as a “stop”, these small pieces of wood attach to a flat frame to give the door a place to stop. Optional draft seal weatherstrip stops are available for use to prevent drafts.*



PRIMED WM-888  
3/8" x 1-1/8"



PRIMED WM-936  
7/16" x 1-3/8"



PRIMED WM-936 W/ DRAFT SEAL  
Draft seal also available in black



PRIMED WM-948  
3/8" x 1-1/8"



PRIMED WM-888H  
1/2" x 1-1/8"



PRIMED WM-876  
7/16" x 1-3/8"



PRIMED WM-876 W/ DRAFT SEAL  
Draft seal also available in black

# Sills



OAK SADDLE SILL



OAK SADDLE SILL WITH WEATHERSTRIP

*Oak saddle sills provide an aesthetic solution to residential threshold applications. If the unit does not include weatherstrip, a standard width saddle sill works well.*

*For flat frames with Draft Seal or single rabbeted frames with weatherstrip, a wider saddle sill works best. It allows the bottom of the frame to sit flush on top of the sill. Three-sided units do not need a sweep, but four-sided units will use a sweep for the best seal.*



# Hinges

## Ball Bearing Hinges

Ball bearing hinges have a steel ball bearing, or buffer, in between the knuckles. Heavier doors put more stress on the hinges, so having the ball bearings reduces friction. This results in better performance and a longer-lasting hinge.



Ball Bearing Square



Ball Bearing Radius



Non Ball Bearing Square



Non Ball Bearing Radius

## Non Ball Bearing Hinges

Standard, or plain bearing, have no buffer between each knuckle of the barrel. This tends to wear the hinge down over time as the sections grind against one another and are better suited for lightweight doors.



3.5" x 3.5"



4" x 4"

## Hinge Sizes

Most interior doors are 1-3/8" thick and use 3.5" x 3.5" hinges. On an 1-3/4" door in an interior application, Reeb® will automatically utilize a 4" hinge.

## Available Finishes

A light gray square sample of the USP Primed White finish.	A solid black square sample of the US1D Flat Black finish.	A bright brass square sample of the US3 Bright Brass finish.	A bright brass square sample of the US3LF* Bright Brass finish, labeled with the Baldwin logo.	A satin brass square sample of the US4 Satin Brass finish.	A bright satin brass square sample of the US4B Bright Satin Brass finish.
<b>USP</b> PRIMED WHITE	<b>US1D</b> FLAT BLACK	<b>US3</b> BRIGHT BRASS	<b>US3LF*</b> BRIGHT BRASS	<b>US4</b> SATIN BRASS	<b>US4B</b> BRIGHT SATIN BRASS
A dark brass square sample of the US5 Antique Brass finish.	A gold square sample of the US7 French Antique finish.	A dark brown square sample of the US10B Oil Rubbed Bronze finish.	A light gray square sample of the US14 Polished Nickel finish.	A light gray square sample of the US15 Satin Nickel finish.	A dark gray square sample of the US15LF* Satin Nickel finish, labeled with the Baldwin logo.
<b>US5</b> ANTIQUE BRASS	<b>US7</b> FRENCH ANTIQUE	<b>US10B</b> OIL RUBBED BRONZE	<b>US14</b> POLISHED NICKEL	<b>US15</b> SATIN NICKEL	<b>US15LF*</b> SATIN NICKEL
A dark gray square sample of the US15A Antique Nickel finish.	A light gray square sample of the US26 Bright Chrome finish.	A light gray square sample of the US26D Satin Chrome finish.	A light gray square sample of the US32D Stainless Steel finish.	A dark gray square sample of the VB Venetian Bronze finish.	A dark gray square sample of the BALDWIN Venetian Bronze finish.
<b>US15A</b> ANTIQUE NICKEL	<b>US26</b> BRIGHT CHROME	<b>US26D</b> SATIN CHROME	<b>US32D</b> STAINLESS STEEL	<b>VB</b> VENETIAN BRONZE	



## BALDWIN

AVAILABLE FINISHES	3.5" X 3.5" SQUARE		3.5" X 3.5" RADIUS		4" X 4" SQUARE		4" X 4" RADIUS	
	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING
US3LF*		X		X		X		X
US10B		X		X		X		
US15LF*		X		X		X		
VB		X				X		

LF\* - Lifetime Warranty

## FREEB SPECIALTY PRODUCTS

AVAILABLE FINISHES	3.5" X 3.5" SQUARE		3.5" X 3.5" RADIUS		4" X 4" SQUARE		4" X 4" RADIUS	
	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING
USP				X				X
US1D		X	X	X		X	X	X
US3	X	X	X	X	X	X	X	X
US4	X	X		X	X	X		X
US4B	X		X	X	X			X
US5	X	X	X	X	X	X	X	X
US10B	X	X	X	X	X	X	X	X
US15	X	X	X	X	X	X	X	X
US15A				X				X
US26	X	X	X	X		X	X	X
US26D	X	X	X	X	X	X	X	X
US32D				X			X	X

## EMTEK®

AVAILABLE FINISHES	3.5" X 3.5" SQUARE SOLID BRASS		3.5" X 3.5" SQUARE STEEL		3.5" X 3.5" RADIUS SOLID BRASS		3.5" X 3.5" RADIUS STEEL		4" X 4" SQUARE SOLID BRASS		4" X 4" SQUARE STEEL		4.5" X 4.5" SQUARE STEEL	
	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING	BALL BEARING	NON BALL BEARING
US1D		X	X	X			X		X	X	X	X	X	
US3		X	X	X		X	X		X	X	X	X		X
US4		X	X						X	X				
US7		X	X	X		X	X		X	X	X	X		
US10B		X	X	X		X	X		X	X	X	X		X
US14		X	X	X			X		X	X	X	X		X
US15		X	X	X		X	X		X	X	X	X		X
US26		X	X	X					X	X	X	X		

# Locks

Schlage® door knobs fit and accentuate decor from a classic look to bold contemporary designs. For available functions, reference the Reeb® In-Stock Price Catalog.

## Standard Residential Series

The **Standard Residential Series** provides tough, reliable performance in a variety of styles and finishes.



**Jazz**  
US15



**Accent**  
US26



**Georgian**  
US5



**Flair**  
US5



**Andover**  
US26



**Latitude**  
US1D



**Plymouth**  
US26D

	<b>Jazz</b>	<b>Latitude</b>	<b>Accent</b>	<b>Flair</b>	<b>Andover</b>	<b>Plymouth</b>	<b>Georgian</b>
<b>US1D</b>		<b>X</b>	<b>X</b>			<b>X</b>	<b>X</b>
<b>US3</b>			<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>
<b>US5</b>			<b>X</b>	<b>X</b>	<b>X</b>		<b>X</b>
<b>US15</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>
<b>US15A</b>			<b>X</b>		<b>X</b>		<b>X</b>
<b>US26</b>			<b>X</b>		<b>X</b>	<b>X</b>	
<b>US26D</b>					<b>X</b>	<b>X</b>	<b>X</b>
<b>716</b>			<b>X</b>	<b>X</b>		<b>X</b>	<b>X</b>

## Standard Residential Series Warranty

The **Standard Residential Series** features a limited lifetime mechanical warranty, has a limited lifetime finish warranty, fits universal backsets, and all levers are non-handed.



## Builders Series

The **Builders Series** provides an economical lock that delivers on style.



**Dover**  
US32D



**Torino**  
US15



**LaSalle**  
US3



**Byron**  
US3



**Marin**  
US32D



**Corona**  
US15

	Dover	LaSalle	Marin	Torino	Byron	Corona
US3		X		X	X	X
US15		X		X		X
US32D	X		X		X	

## Builder's Series Warranty

The **Builder's Series** features a limited lifetime mechanical warranty, a 5-year finish warranty, and fits universal backsets.



## Available Finishes



**US1D**  
FLAT BLACK



**US3**  
BRIGHT BRASS



**US5**  
ANTIQUE BRASS



**US15**  
SATIN NICKEL



**US15A**  
ANTIQUE NICKEL



**US26**  
BRIGHT CHROME



**US26D**  
SATIN CHROME



**US32D**  
STAINLESS STEEL



**716**  
AGED BRONZE

# Catches

Catches are an alternative way to close a door and are often used in closet applications. Ball Catches and Roller Catches are recessed in the top of the door while a Surface Magnetic Catch is installed on the face of the door. A strike is installed on the head frame and the two keep the door closed without the need of a latch. The Concealed Magnetic Catch is recessed into the top of the door and the head frame, which conceals the catch.

## Precision™

Concealed  
Magnetic Catch



	US1D	US3	US5	US10B	US15	US26	US26D	US92
<b>Reeb® Specialty Products</b> Ball Catch	X	X	X	X	X	X	X	
<b>Ives®</b> Surface Magnetic Catch			X					X
<b>Ives®</b> Roller Catch			X		X	X		

## Available Finishes



US1D  
FLAT BLACK



US10B  
OIL RUBBED  
BRONZE



US3  
BRIGHT BRASS



US5  
ANTIQUE BRASS



US15  
SATIN NICKEL



US26  
BRIGHT CHROME




US26D  
SATIN CHROME

# Image Index

PAGE	DOOR STYLE
COVER	PR8720
2	PR8782
7	PR82A
9	PR55R
11	PR8020
13	PR8720
15	PR8760
17	PR8082
18	PR8760
21	PR8010
23	PR8015
25	PR8010F

PAGE	DOOR STYLE
27	PR8490
28	PR8001
29	PR150WL
30	PR8001F
31	PR8711
33	PR8733F
35	PRN730FJ
37	PR732W
39	PR730F
41	PRF2302
42	PRF2315
43	PRF2310

PAGE	DOOR STYLE
45	PR8001/PRT001
47	PR56RFR
49	PR8082FR
50	PR8720FR
52	PR180
53	PR181
54	PR8730
55	PR8720
59	PR8782
65	PR8055



# Index

DOOR STYLE	PAGE	DOOR HEIGHT	3'0" STILE	TOP RAIL	BOTTOM RAIL	LOCK RAIL	PANEL	VENDOR
PR1501WL	29	6/8	4-9/16"	4-9/16"	9-3/32"	N/A	N/A	RSP
PR1501WL	29	8/0	4-9/16"	4-9/16"	9-3/32"	N/A	N/A	RSP
PR180	52	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	9/16"	RSP
PR180	52	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	9/16"	RSP
PR180	52	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	9/16"	RSP
PR181	53	6/8	4-3/8"	4-5/16"	9-3/16"	4-5/16"	9/16"	RSP
PR181	53	7/0	4-3/8"	4-5/16"	9-3/16"	4-5/16"	9/16"	RSP
PR181	53	8/0	4-3/8"	4-5/16"	9-3/16"	4-5/16"	9/16"	RSP
PR44	8	6/8	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
PR44 1-3/4"	8	6/8	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
PR44 BIFOLD	8	6/8	2-5/32"	4-9/16"	8-3/16"	7-1/2"	9/16"	RSP
PR55R	8	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	9/16"	RSP
PR55RFR	47	6/8	5-3/4"	4-9/16"	9-3/16"	N/A	1-1/4"	RSP
PR55RFR	47	7/0	5-3/4"	4-9/16"	9-3/16"	N/A	1-1/4"	RSP
PR56R	8	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	9/16"	RSP
PR56RFR	47	8/0	5-3/4"	4-9/16"	9-3/16"	N/A	1-1/4"	RSP
PR66	8	6/8	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
PR66 BIFOLD	8	6/8	2-5/32"	4-9/16"	8-3/16"	7-1/2"	9/16"	RSP
PR66 1-3/4"	8	6/8	5-3/4"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
PR66FR 1-3/4"	47	6/8	5-3/4"	4-9/16"	9-3/16"	7-1/2"	1-1/4"	RSP
PR730	34	6/8	4-1/4"	4-1/4"	7"	5-1/4"	N/A	RSP
PR730	34	7/0	4-1/4"	4-1/4"	7"	5-1/4"	N/A	RSP
PR730	34	8/0	4-1/4"	4-1/4"	7"	5-1/4"	N/A	RSP
PR730 1-3/4"	26	6/8	4-1/4"	4-1/4"	7"	5-1/4"	N/A	RSP
PR730F	39	6/8	4-3/8"	4-5/16"	9-3/16"	7-3/8"	3/8"	RSP
PR730F BIFOLD	39	6/8	4-3/8"	4-5/16"	9-3/16"	7-3/8"	3/8"	RSP
PR730F 1-3/4"	39	6/8	4-3/8"	4-5/16"	9-3/16"	7-3/8"	3/8"	RSP
PR730F 1-3/4"	39	7/0	4-3/8"	4-5/16"	9-3/16"	7-3/8"	3/8"	RSP
PR730W	37	6/8	4-1/4"	4-5/16"	7-7/16"	5"	N/A	RSP
PR730W BIFOLD	37	6/8	4-1/4"	4-5/16"	6-7/16"	5"	N/A	RSP
PR732	35	6/8	4-1/4"	4-1/4"	7"	5-1/4"	9/16"	RSP
PR732	35	7/0	4-1/4"	4-1/4"	7"	5-1/4"	9/16"	RSP
PR732W	37	6/8	4-1/4"	4-5/16"	7-7/16"	5"	9/16"	RSP
PR742	35	6/8	4-1/4"	4-1/16"	7"	5-3/16"	9/16"	RSP
PR8001	28	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8001	28	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8001F	30	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8001F	30	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8010	21	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8010 1-3/4"	21	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8010F	25	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8012	21	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8012 1-3/4"	21	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8012F	25	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
PR8015	22	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP

# Index

DOOR STYLE	PAGE	DOOR HEIGHT	3'0" STILE	TOP RAIL	BOTTOM RAIL	LOCK RAIL	PANEL	VENDOR
<b>PR8015 1-3/4"</b>	22	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
<b>PR8015F</b>	25	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
<b>PR8018</b>	22	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
<b>PR8018 1-3/4"</b>	22	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
<b>PR8018F</b>	25	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	N/A	RSP
<b>PR8020</b>	10	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8020</b>	10	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8020 1-3/4"</b>	17	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	5/8"	RSP
<b>PR8020 1-3/4"</b>	17	7/0	4-5/8"	4-9/16"	9-3/16"	N/A	5/8"	RSP
<b>PR8020 1-3/4"</b>	17	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	5/8"	RSP
<b>PR8020FR 1-3/4"</b>	49	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	13/16"	RSP
<b>PR8020FR 1-3/4"</b>	49	7/0	4-5/8"	4-9/16"	9-3/16"	N/A	13/16"	RSP
<b>PR8020FR 1-3/4"</b>	49	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	13/16"	RSP
<b>PR8040</b>	11	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8040</b>	11	7/0	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8044</b>	11	6/8	4-5/8"	4-9/16"	9-3/16"	7-1/2"	3/8"	RSP
<b>PR8055</b>	11	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8055</b>	11	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	3/8"	RSP
<b>PR8055FR 1-3/4"</b>	49	6/8	4-5/8"	4-9/16"	9-3/16"	N/A	13/16"	RSP
<b>PR8055FR 1-3/4"</b>	49	8/0	4-5/8"	4-9/16"	9-3/16"	N/A	13/16"	RSP
<b>PR8082</b>	10	6/8	4-5/8"	4-9/16"	9-3/16"	7-5/8"	3/8"	RSP
<b>PR8082</b>	10	8/0	4-5/8"	4-9/16"	9-3/16"	7-5/8"	3/8"	RSP
<b>PR8082 1-3/4"</b>	17	6/8	4-5/8"	4-9/16"	9-3/16"	7-5/8"	5/8"	RSP
<b>PR8082 1-3/4"</b>	17	7/0	4-5/8"	4-9/16"	9-3/16"	7-5/8"	5/8"	RSP
<b>PR8082 1-3/4"</b>	17	8/0	4-5/8"	4-9/16"	9-3/16"	7-5/8"	5/8"	RSP
<b>PR8082FR 1-3/4"</b>	49	6/8	4-5/8"	4-9/16"	9-3/16"	7-5/8"	13/16"	RSP
<b>PR8082FR 1-3/4"</b>	49	7/0	4-5/8"	4-9/16"	9-3/16"	7-5/8"	13/16"	RSP
<b>PR8082FR 1-3/4"</b>	49	8/0	4-5/8"	4-9/16"	9-3/16"	7-5/8"	13/16"	RSP
<b>PR82A</b>	7	6/8	4-5/8"	6-1/2"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82A</b>	7	7/0	4-5/8"	6-1/2"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82A</b>	7	8/0	4-5/8"	6-1/2"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82A 1-3/4"</b>	7	6/8	5-3/4"	6-1/2"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82A 1-3/4"</b>	7	7/0	5-3/4"	8-1/2"	11-3/16"	7-1/2"	9/16"	RSP
<b>PR82A 1-3/4"</b>	7	8/0	5-3/4"	6-1/2"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82AFR 1-3/4"</b>	47	6/8	5-3/4"	6-1/2"	9-3/16"	7-1/2"	1-1/4"	RSP
<b>PR82AFR 1-3/4"</b>	47	7/0	5-3/4"	6-1/2"	9-3/16"	7-1/2"	1-1/4"	RSP
<b>PR82AFR 1-3/4"</b>	47	8/0	5-3/4"	6-1/2"	9-3/16"	7-1/2"	1-1/4"	RSP
<b>PR82R</b>	6	6/8	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82R</b>	6	7/0	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82R</b>	6	8/0	4-5/8"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82R BIFOLD</b>	6	6/8	2-5/32"	4-9/16"	8-3/16"	7-1/2"	9/16"	RSP
<b>PR82R 1-3/4"</b>	7	6/8	5-3/4"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82R 1-3/4"</b>	7	7/0	5-3/4"	6-9/16"	11-3/16"	7-1/2"	9/16"	RSP
<b>PR82R 1-3/4"</b>	7	8/0	5-3/4"	4-9/16"	9-3/16"	7-1/2"	9/16"	RSP
<b>PR82RFR 1-3/4"</b>	47	6/8	5-3/4"	4-9/16"	9-3/16"	7-1/2"	1-1/4"	RSP

# Index

DOOR STYLE	PAGE	DOOR HEIGHT	3'0" STILE	TOP RAIL	BOTTOM RAIL	LOCK RAIL	PANEL	VENDOR
PR82RFR 1-3/4"	47	7/0	5-3/4"	4-9/16"	9-3/16"	7-1/2"	1-1/4"	RSP
PR82RFR 1-3/4"	47	8/0	5-3/4"	4-9/16"	9-3/16"	7-1/2"	1-1/4"	RSP
PR8490	27	6/8	4-7/16"	4-5/16"	9-3/16"	N/A	N/A	SIMPSON
PR8705	44	6/8	2-7/16"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8706	44	8/0	2-7/16"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711	31	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711	31	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711 1-3/4"	31	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711 1-3/4"	31	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711F	32	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711F	32	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711F 1-3/4"	32	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8711F 1-3/4"	32	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8720	13	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8720	13	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8720	13	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8720 BIFOLD	13	6/8	2-1/32"	4-5/16"	8-3/16"	N/A	3/8"	RSP
PR8720 1-3/4"	19	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8720 1-3/4"	19	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8720 1-3/4"	19	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8720FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8720FR 1-3/4"	51	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8720FR 1-3/4"	51	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8730	14	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8730	14	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8730	14	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8730 BIFOLD	14	6/8	2-1/32"	4-5/16"	8-3/16"	N/A	3/8"	RSP
PR8730 1-3/4"	19	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8730 1-3/4"	19	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8730 1-3/4"	19	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	5/8"	RSP
PR8730FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8730FR 1-3/4"	51	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8730FR 1-3/4"	51	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8733F	33	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8733F	33	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8735F	33	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8735F	33	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	N/A	RSP
PR8740	14	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8740	14	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8740FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8740FR 1-3/4"	51	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8744	14	6/8	4-3/8"	4-5/16"	9-3/16"	7-7/16"	3/8"	RSP
PR8755	15	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8755	15	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8755 BIFOLD	15	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP

# Index

DOOR STYLE	PAGE	DOOR HEIGHT	3'0" STILE	TOP RAIL	BOTTOM RAIL	LOCK RAIL	PANEL	VENDOR
PR8755 1-3/4"	19	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8755FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8755FR 1-3/4"	51	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8760	14	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8760	14	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8760	14	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8760FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8760FR 1-3/4"	51	7/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8760FR 1-3/4"	51	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	13/16"	RSP
PR8762	14	6/8	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8762	14	8/0	4-3/8"	4-5/16"	9-3/16"	N/A	3/8"	RSP
PR8782	13	6/8	4-3/8"	4-5/16"	9-3/16"	7-7/16"	3/8"	RSP
PR8782	13	7/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	3/8"	RSP
PR8782	13	8/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	3/8"	RSP
PR8782 BIFOLD	13	6/8	2-1/32"	4-5/16"	8-3/16"	7-7/16"	3/8"	RSP
PR8782 1-3/4"	19	6/8	4-3/8"	4-5/16"	9-3/16"	7-7/16"	5/8"	RSP
PR8782 1-3/4"	19	7/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	5/8"	RSP
PR8782 1-3/4"	19	8/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	5/8"	RSP
PR8782FR 1-3/4"	51	6/8	4-3/8"	4-5/16"	9-3/16"	7-7/16"	13/16"	RSP
PR8782FR 1-3/4"	51	7/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	13/16"	RSP
PR8782FR 1-3/4"	51	8/0	4-3/8"	4-5/16"	9-3/16"	7-7/16"	13/16"	RSP
PRF2302	41	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2302 1-3/4"	41	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2302 1-3/4"	41	7/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2302 1-3/4"	41	8/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2310	43	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2310 1-3/4"	43	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2310 1-3/4"	43	7/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2310 1-3/4"	43	8/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2315	42	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2315 1-3/4"	43	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2315 1-3/4"	43	7/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2315 1-3/4"	43	8/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2355	42	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2355 1-3/4"	42	6/8	N/A	N/A	N/A	N/A	N/A	RSP
PRF2355 1-3/4"	42	7/0	N/A	N/A	N/A	N/A	N/A	RSP
PRF2356 1-3/4"	42	8/0	N/A	N/A	N/A	N/A	N/A	RSP
PRN730FJ BIFOLD	35	6/8	1-1/4"	3-3/16"	3"	3-5/16"	N/A	RSP
PRN732FJ BIFOLD	35	6/8	1-1/4"	3-3/16"	3"	3-5/16"	N/A	RSP
PRT001 TRANSOM	44	1/0	4-1/2"	2-13/16"	2-13/16"	N/A	N/A	RSP
PRT003 TRANSOM	44	1/0	4-1/2"	2-13/16"	2-13/16"	N/A	N/A	RSP
PRT004 TRANSOM	44	1/0	4-1/2"	2-13/16"	2-13/16"	N/A	N/A	RSP
PRT005 TRANSOM	44	1/0	4-1/2"	2-13/16"	2-13/16"	N/A	N/A	RSP

# Reeb® Learning Center

*A Learning Center for  
Everything Door Related*

## Product Education

Sharpen your sales skills with focused insights on Reeb's full product lineup.

## Guided Learning


Build a strong foundation or explore advanced topics with step-by-step learning.

## Short, Engaging Videos

Clear, visual guidance for features, and best practices.

## Manufacturer Videos

Gain insights directly from the source with featured videos from trusted manufacturers.



Start learning today at  
[learn.reeb.com](http://learn.reeb.com)



Free Access



Mobile Friendly



24/7 Availability

## Interior Wood Stile & Rail Doors

Primed Stile & Rail Doors are ideal for painting, but Reeb also stocks Wood Stile & Rail if you are looking for the warm, natural look of real wood. Scan here to view your options.

[www.reeb.com/catalogs](http://www.reeb.com/catalogs)



## Warranty

Scan here to view online warranties for Interior Stile and Rail Doors, along with our other in-stock Reeb products.

[www.reeb.com/warranties](http://www.reeb.com/warranties)



# Handling

## HANDLING & INSTALLATION

Immediately after receipt of your order, inspect each door for any damage or defects.

### NOTIFY YOUR DEALER PROMPTLY OF ANY PROBLEM.

Handle all doors with clean gloves and equipment. Damage caused by handling is not considered a factory defect and is not covered under your warranty.

When moving the doors, avoid dragging the doors across one another or against another surface. Always use two people to lift and move the doors. Avoid leaning the door – they must be stored flat.

Keep the doors covered to maintain cleanliness but remember to allow air circulation.

### THE DOORS SHOULD NOT BE SUBJECT TO ABNORMAL OR EXTREME CHANGES IN TEMPERATURE OR HUMIDITY LEVELS.

Avoid sudden temperature changes, such as forced heat to dry out the building or storage in a building before it is enclosed.

Deliver the doors to the building only after plaster and concrete is dry.

Allow doors at least 48 hours to adjust to the prevailing humidity (become acclimatized) before hanging. Do not expose doors to humidity levels higher than 65%RH, lower than 30%RH, to temperatures above 90 degrees Fahrenheit or to direct sunlight.

Hang doors with adequate clearance to allow for some swelling in damp weather.

Be sure all jambs and stops are set perfectly square and plumb.

The width of the door may be trimmed no more than 1/4" on either side. The height may be trimmed 2" from the bottom rail.

Wood panels "float." Use a hammer and wooden block to adjust the panels if necessary, before installation. Be careful not to damage the surface of the wood.

Use 3 hinges on doors of 7' in height or less. Use 4 hinges on doors over 7' in height.

## INTERIOR FINISHING

### FINISHING PRIMED DOORS

The door should first be fitted and hung in its frame and drilled for all hardware. Then, prior to finishing, the door should be removed from the frame and stripped of all hardware so the finish can be applied with the door laid flat.

The doors are factory primed with an ultra-high-quality primer and have a gloss finish. Prior to finishing, remove all handling marks, labels, surface imperfections and sheen with a light sanding, by hand, using 220 grit sandpaper or a fine grade steel wool. Carefully remove all dust from the door surface.

Your finish should never be applied as a heavy coat. The finish must be applied in multiple light coats with appropriate drying time between each coat. Carefully follow the manufacturer's instructions for drying time between coats.

**□ Bethlehem, PA**

1000 Maloney Cir.  
Bethlehem, PA 18015  
(800) 862-8622 voice  
(800) 772-7332 fax

**□ Barclay, MD**

1315 Goldsboro Rd.  
Barclay, MD 21607  
(800) 825-8331 voice  
(800) 331-9387 fax

**□ Mocksville, NC**

346 Bethel Church Rd.  
Mocksville, NC 27028  
(800) 642-0886 voice  
(800) 618-0620 fax

**□ Providence, RI**

19 Business Park Dr.  
Smithfield, RI 02917  
(800) 343-5703 voice  
(800) 388-5979 fax

**□ Syracuse, NY**

7475 Henry Clay Blvd.  
Liverpool, NY 13088  
(800) 422-5224 voice  
(800) 531-7332 fax



PART# REEBPSR26

VERSION 1.0.0

For more information, visit [reeb.com](http://reeb.com).

COPYRIGHT © 2026 REEB® MILLWORK ALL RIGHTS RESERVED.